




INSTALLATION GUIDE

TR-AXP90X SERIES


Please remove protective sticker before install

www.thermalright.com


parts list



INTEL LGA 115X /1200




Remove pre-install 1700 brackets, install 115X brackets and four screws [B4]
Apply thermal grease on CPU, install heatsink on CPU, four screws through motherboard mounting holes




Install backplate from back side of motherboard, backplate AM4 side face motherboard. Use included tool to secure nuts to screws. If there is motherboard component interfere with backplate, flip the backplate, with 115X side face motherboard, switch short screws on brackets to long screws [B1].

INTEL LGA 1700




Install screws [B4] to 1700 brackets. Apply thermal grease on CPU.
Install heatsink on CPU, four screws through motherboard mounting holes.




Install backplate from back side of motherboard, backplate AM4 side face motherboard. Use included tool to secure nuts to screws. If there is motherboard component interfere with backplate, flip the backplate with 115X side face motherboard, switch short screws on brackets to long screws [B1].

AMD AM5/AM4




Remove motherboard plastic brackets and backplate.
Remove pre-installed 1700 brackets from heatsink.




Install AMD brackets on heatsink. Install screws [B2] on AMD brackets.
Apply thermal grease on CPU. Install heatsink on CPU, four screws through motherboard mounting holes.


AMD AM5/AM4



Install backplate from back side of motherboard with AM4 visible.
Use included tool to secure nuts with backplate and heatsink.
Backplate insulated side must face motherboard.



When motherboard component interferes with backplate. Replace screws on brackets with long screws, long screws through motherboard factory backplate holes. Use nuts to secure long screws and heatsink on CPU.



Connect 4pin PWM connector to motherboard CPU_FAN socket




安装说明

TR-AXP90X 系列


! 安装前请先去除铜底保护膜

www.thermalright.com


配件清单




INTEL LGA 115X/1200



INTEL LGA 1700



AMD AM5/AM4



AMD AM5/AM4

